

Henges INTERIORS

Flooring & Insulation Since 1932

A division of Jay Henges Enterprises, Inc.

rev 11.2025

Items Needed to Schedule Install

Flooring:

1. HVAC
 - a. Permanent or Continuous Temporary Heat or A/C
 - b. Temperatures and parameters for ALL flooring:
 - i. 60 – 80 degrees with a relative humidity of 30%-55% RH.
 - ii. Temps should remain like the home's finished temperature.
 - c. *See below for more information regarding a climatized home.
2. Power
 - a. Dedicated temp pole or generator per home.
3. Access to clean water.
 - a. Proximity within the building lot.
 - b. No lake or creek water is to be used
4. Substrate is scrapped and swept.
5. Excessive edge swell or plywood gaps are identified.
6. Eliminate any high screw heads or nails.
7. Painting is completed.
 - a. Ideally 24 to 48 hours before flooring installation.
8. Concrete flatwork is completed.
 - a. Specifically, basements, garage & front porches.

*NOTE:

For the best performance of all flooring materials make sure our homes are properly acclimated / climatized before and after installation of flooring. Homes being climatized to an acceptable condition before, during and after our installation ensure the materials and the substrate meet the proper guidelines for a professional, quality, and warrantable install. It is critical for these products to remain in a stable environment and maintain a constant temperature.